

i-con edger

installation guide



Congratulations on purchasing the finest concrete edger system available.

Step-by-Step Installation

The directions in this guide are for the installation of barkman I-Con Edgers. Before you start it is important to have your project fully designed on paper. If you require assistance with creating your design, or have any further questions regarding installation, please consult your barkman dealer.

Equipment Needed

- Sand or clean granular fill
- Wheelbarrow, carpenter's level, gloves, safety glasses
- Flat spade, hammer and chisel
- Rubber mallet
- Concrete saw with a diamond blade (available at rental store)
- Ruler and/or tape measure





estimating

i-con edger




$3\frac{5}{8}'' \times 12'' \times 4''h$

Units Needed

length (in feet)	=	number of units
------------------	---	-----------------

Using a can of spray paint, or a long piece of garden hose, trace out the desired design for your edging on the ground. Now measure the total length of the line created to determine the number of edging units you will require.



1

Create Design

Using a can of spray paint, or a long piece of garden hose, trace out the desired design for your edging on the ground. Determine the number of edging units you will require (see estimating).

2

Align I-Con Edgers

Before you begin to excavate, take your I-Con Edgers and place them along the pattern they will follow. This allows you to make any final adjustments to your design, should they be necessary.

3

Determine Trench Depth

Before digging, determine how deep your trench should be, keeping in mind that you will require about an inch of base material beneath the stones and stone height is 4" (you will need a trench about 5" deep if you want your stones flush with the ground).

4

Excavate Trench


Using a flat spade, excavate your trench, removing any rocks or roots that may be present.



5

Prepare Trench Base

Add about 1" of sand or coarse granular material along the bottom of your trench. Level off base material.



6

Place I-Con Edgers

Now, place the I-Con Edgers, being careful each Edger is level front to back and side to side before proceeding to the next. Add or remove base material as required.



7

Cutting Edgers to Size

I-Con Edgers may be cut using a concrete saw to accommodate an abrupt change in direction or end of a run. Before cutting, be sure to read and follow directions on saw use. Wear safety glasses.

barkmanconcrete.com

Barkman Concrete Limited

Steinbach Office

152 Brandt Street

Steinbach, MB R5G 0R2

T (204) 326 3445 or

1 800 461 2278

F (204) 326 5915

steinbach@barkmanconcrete.com

Winnipeg Office

909 Gateway Road

Winnipeg, MB R2K 3L1

T (204) 667 3310 or

1 800 342 2879

F (204) 663 4854

winnipeg@barkmanconcrete.com

Vancouver Office

2104 – 290 Newport Drive

Port Moody, BC V3H 5N2

T (778) 689 7670

F (604) 949 0321

vancouver@barkmanconcrete.com

Calgary Office

813 McCool St Box 1136

Crossfield, AB T0M 0S0

T (403) 946 4630

F (403) 946 4631

calgary@barkmanconcrete.com

creating
concrete
solutions

barkman[™]

Caution: Before any digging, always consult your local utility companies for the location and depth of pipes, cables and conduits. Dry sawing or grinding of concrete products may result in the release of respirable crystalline quartz. Prolonged exposure to respirable crystalline quartz may cause delayed (chronic) lung injury (silicosis). The use of a NIOSH-approved respirator and tight fitting goggles is recommended when sawing or grinding operations are in progress.

MF21132-0711